

ASSEMBLY INSTRUCTIONS

VANITY LINER CABINET

| Part | Descriptions | Qty | Part | Description | Qty | Part | Description | Qty |
|---------|----------------------|-----|------|----------------------------|-----|------|--------------|-----|
| A,B,C,D | Drawer Parts | 4/2 | J | Back Panel | 1 | P | Corner Brace | 0 |
| E | Slide With Screws | 2 | K | Toe Kick | 1 | Q | Shelf | 4 |
| F | Face-frame with Door | 1 | L | Screw $\phi 3.5 \times 25$ | 24 | R | Shelf Clip | 16 |
| G | Side Panel | 2 | M | L-Shaped Steel | 8 | | | |
| H | Top and Bottom Panel | 2 | N | L-Shaped Steel | 2 | | | |
| I | Shelf With Cleat | 2 | O | Screw $\phi 3.5 \times 12$ | 24 | | | |

This instructions applies to the following items: **VLCD188421**.



****Optional to add glue, it's helpful to add strength** (wood glue not included)**

STEP 1: Slide-in the Sides to the Frame.

STEP 2: Slide-in the Top and Bottom.

STEP 3: Slide-in the Back to the Cabinet Box.

STEP 4: Secure the Corners of the Box by using the L-Shaped Steel.

